

KALIBRERINGSTABELL

Gäller för samtliga Protimeter Vattenhaltsmätare

2000-2001

Anvisning

Avläs med på veteskalen och ta värdet och gå in i tabellen under raden Vete-Råg (avläst värde). Ta det värde som ligger närmast i kolumnen och för ner till önskad sort.

	Skala 0-100	5	10	14	17	20	23	27	30	33	37	39	42	47	52	50	67	73	78	84
	Vete-Råg Avläst värde	11.3	12.3	12.8	13.3	13.8	14.3	14.8	15.3	15.8	16.3	16.8	17.3	18.3	19.3	21.3	23.3	25.3	27.3	29.3
H	Vete-Råg	12.8	13.4	13.8	14.3	14.9	15.5	16.2	16.8	17.5	18.2	18.8	19.4	20.4	21.3	23.0	25.0	27.2	29.5	
M	KornHavre	10.9	11.8	12.3	12.8	13.3	13.8	14.3	14.8	15.4	16.0	16.7	17.2	18.2	19.2	20.8	22.6	24.5	26.7	29.3
H	KornHavre	12.9	13.5	13.9	14.4	14.8	15.3	15.8	16.5	17.1	17.8	18.4	19.0	20.2	21.4	23.5	26.0	28.5	31.0	
H-M	Bönor, Tickbönor	12.4	13.4	13.7	13.9	14.1	14.5	15.0	15.4	16.0	16.5	16.9	17.3	17.9	18.6	19.7	20.9	22.1	23.4	25.0
M	Kålför	7.3	7.9	8.3	8.8	9.1	9.3	9.5	9.8	10.0	10.3	10.5	11.0	11.4	12.3					
H	Buckvete	12.1	12.8	13.4	13.8	14.2	14.6	15.1	15.6	16.2	16.8	17.3	17.8	18.9	19.9	21.6	23.5	25.6	27.5	29.6
H	Rödklöver, Lucern	9.1	9.9	10.3	10.7	11.1	11.6	12.0	12.3	12.8	13.2	13.6	14.0	14.9	15.6	16.9	18.4	20.0		
H	Vitklöver	9.0	9.9	10.3	10.8	11.3	11.8	12.3	12.8	13.3	13.8	14.3	14.8	15.7	16.6	18.1	20.0	21.9	23.4	
H	Kakaoböner	3.9	4.5	4.8	5.1	5.5	5.8	6.1	6.4	6.7	7.1	7.4	7.7	8.1	8.5	9.2	9.8	10.3		
M	Kaffeböner		10.2	10.5	10.9	11.2	11.6	12.1	12.6	13.1	13.5	13.9	14.3	15.0	15.7	17.1	19.5			
H	Kaffeböner	9.8	10.7	11.3	11.9	12.8	13.5	14.3	15.2	16.0	16.8	17.6	18.2	19.4	20.4	22.3	23.9			
M	Kaffeböner/ gröna		10.2	10.9	11.6	12.3	12.8	13.3	13.8	14.3	14.7	15.1	15.5	16.2	16.9	18.3	20.7			
H	Lin hel	6.9	7.4	7.7	8.0	8.5	8.8	9.1	9.4	9.9	10.3	10.7	11.1	12.0	13.0	14.6				
M	Vetemjöl	12.9	13.7	14.1	14.5	15.0	15.4	15.9	16.3	16.8	17.2	17.7	18.2	19.1	19.9	21.3	23.0			
H	Gräsför Hundäxling	8.3	9.2	9.6	10.0	10.5	10.9	11.3	11.8	12.3	12.8	13.2	13.6	14.5	15.2	16.6	18.4	20.3		
H	Gräsför Rajgräs	10.4	11.3	11.7	12.2	12.7	13.2	13.7	14.2	14.7	15.3	15.8	16.3	17.4	18.5	20.2	22.4			
H	Jordnötter, skalade	5.5	6.1	6.4	6.6	6.9	7.1	7.3	7.6	7.9	8.1	8.4	8.6	9.0	9.5	10.4				
H-M	Linser	11.2	12.3	12.5	12.7	13.0	13.4	13.7	14.0	14.4	14.8	15.0	15.3	16.0	16.6	17.9				
H	Linfrö	7.0	7.4	7.7	8.0	8.3	8.7	9.0	9.4	9.9	10.3	10.7	11.1	12.0	12.9	14.6	16.5			
M	Majs	10.4	11.4	11.9	12.4	13.0	13.5	14.0	14.6	15.2	15.8	16.4	16.9	17.8	18.2	20.0	21.6	23.1	24.6	26.2
H	Majs	11.4	12.0	12.5	13.1	13.5	13.9	14.3	14.8	15.4	15.9	16.5	16.9	17.9	18.7	20.2	21.9	23.6	25.2	27.2
H	Senapsfrö	7.7	8.2	8.6	9.0	9.4	9.8	10.1	10.6	11.2	11.7	12.1	12.5	13.6	14.5	16.1				
M	Raps					7.0	7.3	7.7	8.3	8.9	9.4	9.8	10.2	11.0	12.0	13.9	16.5	19.0	22.0	26.0
H	Raps för vägledning		7.2	7.7	8.3	9.0	9.5	10.1	11.0	11.8	12.6	13.4	14.1	15.3	16.7	19.1	22.6			
H	Råris	10.1	11.0	11.5	11.9	12.3	12.8	13.3	13.8	14.4	15.0	15.6	16.2	17.3	18.3	20.3	22.6	24.8	27.0	29.4
M	Råris	10.4	11.4	11.9	12.4	13.0	13.5	14.0	14.6	15.2	15.8	16.4	16.9	17.8	18.2	20.0	21.6	23.1	24.6	26.2
M	Årtor	12.0	12.9	13.5	14.0	14.5	15.0	15.7	16.2	16.8	17.5	18.0	18.5	19.5	20.1	22.5	24.3	26.2	28.2	30.9
H	Årtor	9.4	10.3	10.8	11.3	11.9	12.5	13.0	13.6	14.3	14.9	15.5	16.1	17.3	18.3	19.8	21.7	23.5	25.2	27.1
H	Ris		13.2	13.7	14.2	14.8	15.2	15.7	16.3	16.9	17.5	18.2	18.8	20.0	21.2	23.3	26.5			
H-M	Semolina	12.3	13.0	13.2	13.6	14.0	14.5	15.1	15.5	16.2	16.8	17.2	17.8	18.7	19.4	21.0	22.4			
M	Sorghum	10.2	11.7	12.2	12.7	13.1	13.6	14.1	14.6	15.1	15.6	16.1	16.6	17.4	18.2	19.6	21.4	23.0	24.7	26.9
H	Sorghum	11.2	12.2	12.7	13.2	13.7	14.2	14.7	15.2	15.8	16.3	16.9	17.3	18.2	19.1	20.6	22.5	24.2	25.9	28.0
M	Sojaböner	7.4	8.2	8.7	9.1	9.7	10.1	10.6	11.1	11.6	12.0	12.5	12.9	13.8	14.7	16.0	17.5	19.9	20.4	22.2
H	Sojaböner	9.3	10.4	10.7	11.1	11.5	11.9	12.4	13.0	13.6	14.3	14.9	15.4	16.5	17.6	19.6	21.8	23.7	25.9	28.6
H	Socketbetsfrö	7.6	9.4	8.7	9.1	9.6	10.0	10.3	10.8	11.2	11.6	12.0	12.4	13.2	13.8	14.8	16.1	17.3	18.6	20.2
H	Solrosfrö	6.2	6.9	7.3	7.7	8.2	8.5	8.9	9.4	9.9	10.5	11.1	11.6	12.5	13.5	15.3	17.7	20.3	23.0	

M= Malt prov

H= Helt prov

Notera

Kalibrering av de olika grödorna kan variera med växtåren, tillse att uppdatera tabellen.
En vanlig felorsak är utebliven skötsel av instrumentet, läs medföljande skötselanvisning.
Om fel uppstår, kontakta..



Box 2

270 35 BLENTARP

tel: 0416-13550 mobil:070-5413550